



**WARNING**



**NO ENTRY**

Ultraviolet Radiation Lamp In Operation

**AUDIO/ VISUAL INDICATORS**

STATUS	AUDIO	VISUAL
Ready to operate	-	Green LED- solid
Delayed start	Continuous (increased frequency for the last 10 seconds)	Red LED- flashing (increased frequency for the last 10 seconds)
Lamp strike	-	Red LED- solid
Emitting	Single ping per 10 seconds	Red LED- solid
Motion interruption	Dual ping per 10 seconds	Red + Green LED- flashing
End of cycle	Triple ping, 3 times	Green LED- solid